



Prism
Lighting Group

SHOW  BATTERY™
tradeshow battery packs

SHOW100 Rechargeable Battery



INSTRUCTIONS

ABOUT OUR UNIT:

- Portable Rechargeable Battery System
- Lithium Ion Battery
- 22.2 Volts / 4.4 Amps
- LED Battery Level Indicator
- (Optional) Travel Pouch

CONTACT INFORMATION:

If you have questions about your new ShowBattery Model SHOW100, please contact us using the information below:

United States

Email: salesusa@prismlightinggroup.com

Phone: 1-866-620-1380 x102

Website: www.prismlightinggroup.com

Canada

Email: salesca@prismlightinggroup.com

Phone: 1-866-620-1380 x101

Website: www.showbattery.com

CAUTION



- Store and Charge unit in dry location
- Storage temperature between -10° to 50° Celsius
- Do not expose unit to extreme heat
- Do not disassemble
- Do not immerse unit in water
- Do not reverse the polarity of the battery
- Recharge Fully Before Storage

Before using, please read:

Use only approved light fixtures and devices with the SHOW100 Lithium Ion Battery Pack. Non-approved fixtures may result in overloading of the unit and cause failures to occur. Please refer to our website FAQ or contact us at info@prismlightinggroup.com with any questions.

Charge only with our power supply. **DO NOT**, under any circumstances, use third party power supplies to charge the unit, as it may result in overcharging and injury.

After every use, charge the SHOW100 fully before it is put away in storage.

For transporting of the unit, do not transport if unit has been damaged. Disconnect all lights and charging devices before transporting. Store properly with protective wrap while transporting to avoid damage to the battery. Please refer to our website, or email us for advice on proper transportation methods for lithium batteries.



1 x Charger

1 x Battery Pack

2 x Extension Light Cable



1 x Y-Cable Splitter



*Optional Storage Pouch


THE PACKAGE INCLUDES:

- 1 x Charger
- 1 x Y-cable Splitter
- 2 x Extension Light Cable
- 1 x SHOW100 Lithium Ion Battery Pack
- (Optional) Storage Pouch

PLEASE FOLLOW CHARGING INSTRUCTIONS TO MAINTAIN FULL USAGE OF THE SHOW100 UNIT

BATTERY INDICATOR:

Press on the Red Battery Indicator Button. It will display either Green, or Red. Each LED represents 20% of charge. If the indicator is RED, recharge immediately before usage.



POWER INLET / OUTLET:

This is attached to the battery. Connect the Charger to this socket when charging. After charging, disconnect. Connect with our designated connectors to power up the lights.

*use only show battery chargers, and connectors. Refer to our safety and caution information.

